


WALL PLANKS INSTALLATION INSTRUCTIONS

1. Measure the height of the installation area in feet. For example, you have 8' and plus 4" which you need to distribute between 8 rows. So your covering length should be 1' plus 4" / 8 = 1/2". I.e. 12-1/2". Start installation from the bottom of the wall and install the first row. To alternate the shift of vertical seams use Starter/End planks. The bottom of your next row will be at 12-1/4" (in our example). Use the best looking end of each plank on the bottom.




2. To make starter/end pieces: using metal ruler make few deep cuts with utility knife on both sides. Use the edge of the table to break pieces down to two starter/end planks. The other option to cut planks is to use a miter or table saw if it will allow to cut a 16" length. Cutting in length: use miter saw to cut boards to the desired lengths if needed.



3. Use 1.5-1.75" finishing nails # 18 for the nail gun (adjust gun to deliver nails flush to the surface of wood), or use loose nails # 16 of 1.5-2" long for hammer installation.



4. Attach planks to the wall with at least 4 nails on the top part of the planks. Step at least 1 in. from side or end of the planks to put a nail. Considered that the next row of the planks will overlap the nails marks from the previous line.



5. If you need to attach wall art or shelves on top of the wall planks, drill the holes and put hangers through the planks on your wall. Don't hang anything heavier than 0.5 lbs. on the planks themselves!